

AIR INTAKE & THROTTLE BODY CLEANER

PRODUCT OVERVIEW

Air Intake & Throttle Body Cleaner gently removes sticking residues like oil, resin, grease and dirt. The product evaporates within seconds without leaving any residue behind. Ensures proper function of the throttle body, perfect power transmission, stable engine idle and prevents stalling.

APPLICATION

Air intake system.

DIRECTIONS

Shake can well before use. Spray liberally over parts to be cleaned. Allow product to evaporate or wipe parts with a clean cloth. Repeat steps 1-3 if necessary.

REACTION TIME

Approx. 30 – 60 seconds

IDENTIFICATION

ID	Size	Case Qty
PWT2801	500ml	12



This information has been carefully checked for accuracy. However, all information supplied is non-binding advice. No liability is accepted for printing issues, technical modifications or errors.